

DASH
OFFROAD


JIMNY
BULLBAR





INSTALLATION
INSTRUCTIONS

JIMNY BULLBAR

INSTALLATION INSTRUCTIONS



- | | | | | | |
|---|---------------------------------------|---|----------------------------|--|--|
|  | 15 X M6 WASHERS |  | 4 X M10X90MM BOLTS |  | 14 X M12 FLANGE NUTS |
|  | 24 X M10 WASHERS |  | 2 X M10X70MM BOLTS |  | 38 X M12 WASHERS |
|  | 6 X M12 WASHERS |  | 6 X M12X35MM BOLTS |  | 4 X M6X15MM BUTTON HEAD BOLTS - Stainless Steel |
|  | 6 X M12 LOCK NUTS |  | 8 X M12X65MM BOLTS |  | 4 X M6 WASHERS - Stainless Steel |
|  | 6 X M10 LOCK NUTS |  | 12 X M10X25MM BOLTS |  | 4 X M6 FLANGE NUTS |
|  | 15 X M6X15MM BUTTON HEAD BOLTS | | |  | 2 X RED PLASTIC INSERTS |
|  | 6 X M12X30MM BUTTON HEAD BOLTS | | |  | 10 X M12 BOLTS |
|  | 15 X M6 BOLTS | | | | |

JIMNY BULLBAR


INSTALLATION INSTRUCTIONS



1. Remove the grille and backing support panel.
To remove the bumper remove the 3 plastic clips at the top and 2 outer top bolts



2. Remove the 2 clips on the inner guard



3. Remove the 3 bolts along the bottom of the bumper and remove bumper from the car





JIMNY BULLBAR



INSTALLATION INSTRUCTIONS



4. Drill the factory holes larger. 10mm for the 2 inside holes, 16mm for the 2 outside holes.



5. Assemble the winch cradle with the two single M12 front bolts first. Then fit to the Jimny with the 2 rear M12x90mm bolts with Crush tubes and large washers. Once fitted check its level and tighten all bolts.



JIMNY BULLBAR


INSTALLATION INSTRUCTIONS



6. Fit the captive nut and M10 bolt as below to either side of the winch cradle



7. Insert the backing plate with 2x M10x70mm bolts and crush tubes in front of the radiator and through to the winch cradle and fit nuts and washers
If winch is also being installed, fit this now.




JIMNY BULLBAR

INSTALLATION INSTRUCTIONS



8. Mask and paint the frame below black to help create a shadow line when the bar is fitted



9. Fit the brackets to the bullbar with M12x30mm Button head bolts, measure the width of the cradle mounts and ensure bar mounts match so the bar can slide straight on.



10. At the same time as fitting the brackets fit lightbar inside hoop and bolt the hoop to the bar with the two top bracket bolts




JIMNY BULLBAR


INSTALLATION INSTRUCTIONS



11. Fit the bar to the winch cradle with 3 x M12x80mm bolts, fit loosely first, align to fit then tighten all bolts.



12. Mount wing support brackets with M10x20mm Bolts



JIMNY BULLBAR

INSTALLATION INSTRUCTIONS



13. Remove the headlight washers from the factory bar and connect to the bullbar



14. Mount the red backing and fog lights to fog light surrounds, wire up the fog lights and fit surround to the bar with M6 Button Head bolts



JIMNY BULLBAR

INSTALLATION INSTRUCTIONS



15. Fit the bash plate to the bar with 3x M6 Button head bolts along the front and 3 M6 Bolts along the rear



16. Trim the bottom plastic inner wheel arches to align with the bottom of the bar

